

# OPERATOR'S MANUAL



## 快打 獅子皇帝

SS710244

### ◀ 取扱説明書 ▶

POWER SUPPLY	DC+5V DC+12V
MONITOR	VERTICAL SCREEN
GAME STYLE	2-PLAYER SIMULTANEOUS

 **FACE** CO.,LTD.

## CONNECTOR DIAGRAM


SOLDER SIDE	NO.	NO.	PARTS SIDE
GND	A	1	GND
GND	B	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
-5V	E	5	-5V
+12V	F	6	+12V
	H	7	
COIN COUNTER 2	J	8	COIN COUNTER 1
	K	9	
SPEAKER(-)	L	10	SPEAKER(+)
	M	11	
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
TEST SW	S	15	
COIN SW 2	T	16	COIN SW 1
2-P START	U	17	1-P START
2-P UP	V	18	1-P UP
2-P DOWN	W	19	1-P DOWN
2-P LEFT	X	20	1-P LEFT
2-P RIGHT	Y	21	1-P RIGHT
2-P SW 1 BUTTON	Z	22	1-P SW 1 BUTTON
2-P SW 2 BUTTON	a	23	1-P SW 2 BUTTON
	b	24	
	c	25	
	d	26	
GND	e	27	GND
GND	f	28	GND

## HOW TO PLAY

- ショットとミサイル・ボムを使い、敵を倒します。
- 6つのステージをクリアするとエンディングです。
- Attack the enemy with the shot and missile bomb.
- Game is over when you clear six stages.

## CONTROL PANEL

Controls your Figter.



Joystick

Shot  
Sub Weapon



Button-A

Special  
Weapon



Button-B

## DIP-SWITCH 1

		[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]
Fighters	●3 ●1 ●2 ●5	* OFF ON OFF ON	* OFF OFF ON ON						
Bomb	●3 ●1 ●2 ●5			* OFF ON OFF ON	* OFF OFF ON ON				
Difficulty	●Easy ●Normal ●Hard ●Super Hard					OFF * ON OFF ON	OFF * OFF ON ON		
Extend Player	●200,000 and 500,000 ●100,000 and 300,000 ●500,000 and 1,000,000 ●1,000,000 and 3,000,000							* OFF ON OFF ON	* OFF OFF ON ON

## DIP-SWITCH 2

		[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]
Coin 1	●1 COIN = 1 CREDIT ●2 COINS = 1 CREDIT ●3 COINS = 1 CREDIT ●4 COINS = 1 CREDIT ●5 COINS = 1 CREDIT ●6 COINS = 1 CREDIT ●1 COIN = 2 CREDITS ●1 COIN = 3 CREDITS ●1 COIN = 4 CREDITS ●1 COIN = 5 CREDITS ●1 COIN = 6 CREDITS ●2 COINS = 3 CREDITS ●3 COINS = 2 CREDITS ●5 COINS = 3 CREDITS ●8 COINS = 3 CREDITS ●FREE PLAY	* OFF ON OFF ON OFF ON OFF ON ON OFF ON OFF ON ON OFF ON ON ON ON	* OFF OFF ON ON OFF ON ON ON OFF ON ON OFF ON ON ON ON ON ON	* OFF OFF OFF OFF ON ON ON OFF OFF ON ON ON ON ON ON ON ON ON	* OFF OFF OFF OFF OFF OFF ON ON ON ON ON ON ON ON ON ON ON ON				
Screen Revers	●Normal ●Invert					* OFF ON			
Continue	●ON ●OFF						* OFF ON		
Demo Sound	●ON ●OFF							* OFF ON	
Test Mode	●OFF ●ON								* OFF ON

■ Demo SoundがOFFの時は、コイン待ちデモの時に音が鳴らないようになります。

■ When DEMO-SOUND is "OFF", there will be no sound during demonstration mode.

\* 出荷時の設定

\* INDICATES FACTORY SETTING.



株式会社 **フェイス** 〒164 東京都中野区弥生町2-26-2 第2Kビル TEL.03(3229)1101 FAX.03(3229)3555  
OFFICE:DAI2 K BLD. 2-26-2 YAYOI-CHO, NAKANO-KU,TOKYO 164, JAPAN  
TEL.03(3229)1101 FAX.03(3229)3555